


INSTRUCTIONS SCOOTER CARPET CLEANER

1. Using 5, 10, 20 or 30-gallon container, fill with hot water and mix 2 oz per gallon of Steam Shampoo. Connect solution Line (only) to machine and Spray wand before turning the pump on.




NOTE: Depress Floor Wand Trigger until air is out of Line and pressure builds up. Pump will cut off automatically when max 100 P.S.I. is reached.

2. Place Solution Line (grey hose) off the back of machine into bucket of hot water.




Turn only the Pump Switch on. Pre Spray all spots and traffic lane areas. Add Foam Alone 1-2 oz. into Dirty Water Tank. This will knock out soap Residue that is in the carpet. If not used, could cause dirty water tank to overflow.

NOTE: You can also use the kitchen sink or bathtub for your fresh water source.



3. Connect Solution Water Hoses to machine and Floor Wand. Do not turn pump on until you connect these hoses. Also connect Vacuum Hose.

NOTICE: Quick disconnect must be pulled all the way back to insert into the machine coupling, and wand coupling.



Wand will not release spray unless this is done. Depress trigger control continuously until water solution sprays out bottom of the wand. Solution hose line must be in water at all times.

Note: pre spray using magnum blue using wand with vacuum motor off. Steam clean with the same



4. You are now ready to clean carpets. Turn Vacs & pumps on. Spray solution from wand using a forward and reverse action, until carpets are clean.

Then release Spray Solution and Vacuum only with 3 or 4 strokes. This will give you a faster dry time. **Note:** use magnum blue for pre pray.

5. The proper release of dirty water is in the commode. Place the Scooter Dump Valve over commode and pull handle. Commode will flush automatically with the force of the dirty water.




Flush dirty water tank out with clean water. Remember you can use the bathtub for your solution tank or fresh water source. Just fill up and add chemicals.

NOTE: FOR FASTER DRYING USE NAMCO'S CARPET BLOWERS


INSTRUCCIONES-LIMPIADOR DE ALFOMBRAS SCOOTER

1. Utilice un contenedor de 5, 10, 20 o 30 galones, llénelo con agua caliente. Mezcle 2 oz de Steam Shampoo. Conecte la manguera de la solución (solamente) a la maquina y conecte




la Wand antes de encender la bomba.

NOTA: Presione el disparador de la Pistola de Rociar hasta que salga el aire de la manguera y haya presión. La bomba se apagará automáticamente cuando alcance el máximo de los 100 PSI




2 Introduzca la Manguera de Solución (manguera gris) conectada atras de la maquina en el contenedor. Encienda el Switch de la Bomba solamente. Pre-rocie todas las manchas y lineas en las áreas de tráfico. Añada 1-2 oz. de Foam Alone en el Tanque de Agua Sucia. Esto eliminará el residuo de jabón en la carpeta, si no se usa, podría causar que el Tanque de Agua Sucia se derrame. **NOTA:** Puede usar tambien el zink de la cocina o la bañera para fuente de agua limpia.



3. Conecte las mangueras de aspirar y la manguera solución a la máquina y al wand. No encienda la bomba hasta que estas mangueras sean conectadas.

NOTA: El desconector rápido debe de halarse totalmente hacia atrás para insertarlo en los acopladores de la máquina y wand.




Si no se acoplan correctamente el wand no liberará o soltará solución. Oprima el control del gatillo o disparador del wand hasta que la solución sea disparada por la parte inferior del wand. La manguera de solución debe de mantenerse todo el tiempo en el agua. **Note:** Rocie magnum blue usando un wand con los motores apagado. y limpie utilizando el mismo químico magnum blue

4. Ya se está listo para limpiar alfombras. Encienda la máquina subiendo los interruptores del aspirador y bomba. Rocíe la solución con el wand, utilizando la acción de hacia adelante y hacia atrás, hasta que la alfombra esté totalmente limpia.

Luego libere la solución y el sistema de aspirado solamente con 3 o 4 aplicaciones. Esto reducirá el tiempo de secado.

Note: Pre Rociar magnum blue.

5. El desecho apropiado del agua sucia es en la cómoda (cuarto de baño). Coloque la válvula de descarga del Scooter sobre la cómoda y hale el mango hacia arriba.



La cómoda desechará el agua automáticamente con la presión generada. Finalmente limpie el tanque de agua sucia. Recuerde, tambien puede usar la bañera como tanque para solución o como fuente de agua limpia. Solamente llenela y agregue los químicos.

NOTA: PARA UN SECADO RAPIDO DE LAS ALFOMBRAS USE LOS BLOWERS DE NAMCO